

# OWNER'S MANUAL

- ASSEMBLY
- OPERATION
- MAINTENANCE
- PARTS LIST

**Model No.**  
**248-640A**


USE KIT

*4 1/2 gallons 10W 30 Oil*

## Important:

**Read Safety Rules and  
Instructions Carefully**

**LOG SPLITTER**



# LIMITED WARRANTY

For one year from the date of original retail purchase, MTD PRODUCTS INC will either repair or replace, at its option, free of charge, F.O.B. factory or authorized service firm, any part or parts found to be defective in material or workmanship. Transportation charges under this warranty must be paid by the purchaser unless return is requested by MTD PRODUCTS INC.

This warranty will not apply to any part which has become inoperative due to misuse, excessive use, accident, neglect, improper maintenance, alterations, or unless the unit has been operated and maintained in accordance with the instructions furnished. This warranty does not apply to the engine, motor, battery, battery charger or component parts thereof. Please refer to the applicable manufacturer's warranty on these items.

This warranty will not apply where the unit has been used commercially.

Warranty service is available through your local authorized service dealer or distributor. If you do not know the dealer or distributor in your area, please write to the Customer Service Department of MTD.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

## WARNING TO PURCHASERS OF INTERNAL COMBUSTION ENGINE EQUIPPED MACHINERY OR DEVICES IN THE STATE OF CALIFORNIA

The equipment which you have just purchased does not have a spark arrester. If this equipment is used on any forest covered land, brush covered land, or grass covered unimproved land in the State of California, before using on such land, the California law requires that a spark arrester be provided. In addition, spark arrester is required by law to be in effective working order. The spark arrester must be attached to the exhaust system and comply with Section 442 of the California Public Resources Code.

# ➡ IMPORTANT

It is suggested that this manual be read in its entirety before attempting to assemble or operate. Keep this manual in a safe place for future reference and for ordering replacement parts.

This unit is shipped WITHOUT GASOLINE or OIL. After assembly, see operating section of this manual for proper fuel and amount.

Your log splitter is a precision piece of power equipment, not a plaything. Therefore exercise extreme caution at all times.

## SAFE OPERATION PRACTICES FOR LOG SPLITTERS

### TRAINING

1. Know the controls and how to stop quickly--  
READ THE OWNER'S MANUAL.
2. Do not allow children to operate. Do not allow adults to operate it without proper instruction. Only persons well acquainted with these rules of safe operation should be allowed to use your log splitter.
- C. Open doors if engine is run in garage--exhaust fumes are dangerous. Do not run engine indoors.
6. Always operate the log splitter from the engine side of the beam.

### PREPARATION

1. Do not wear loose fitting clothing that could get caught on the moving parts.
2. Do not operate equipment when barefoot or wearing open sandals. Always wear substantial footwear.
3. Check the fuel before starting the engine. Do not fill the gasoline tank indoors, when the engine is running, or while the engine is still hot. Wipe off any spilled gasoline before starting the engine.
4. Use only in daylight or in good artificial light.
5. Never operate the equipment in the rain. Always be sure of your footing.


### OPERATION

1. Do not change the engine governor settings or overspeed the engine. Excessive engine speeds are dangerous.
2. Do not put hands or feet near rotating or moving parts.
3. If the equipment should start to vibrate abnormally, stop the engine and check immediately for the cause. Vibration is generally a warning of trouble.
4. When cleaning, repairing or inspecting, make certain all moving parts have stopped. Disconnect the spark plug wire, and keep the wire away from the plug to prevent accidental starting.

Handle gasoline with care--it is highly flammable.

- A. Use approved gasoline container.
- B. Never remove cap or add gasoline to a running or hot engine or fill fuel tank indoors. Wipe up spilled gasoline.

Stand behind the ram when operating. See drawings.



7. Be careful not to touch the muffler after the engine has been running, it is HOT.

### MAINTENANCE and STORAGE

1. Keep all nuts, bolts, screws, hose clamps and hydraulic fittings tight to be sure equipment is in safe working condition.
2. Never store the equipment with gasoline in the tank inside of a building where fumes may reach an open flame or spark. Allow the engine to cool before storing in any enclosure.
3. To reduce fire hazard keep engine free of grass, leaves, wood chips, excessive grease and oil.
4. Do not change the engine governor settings or overspeed the engine. Excessive engine speeds are dangerous.
5. Never store outside without a waterproof cover. Rain will cause rust on the inside of the cylinder.

# ASSEMBLY INSTRUCTIONS

1. Remove the log splitter, parts pack all literature from the crate before discarding crate.
2. Block up rear end of log splitter so that the rear wheels may be assembled.
3. Place flat washers (A) on axle, then wheels and secure with collars and set screws (B). See figures 1 and 2.




FIGURE 1




FIGURE 2

4. The engagement handle is partly assembled, pivot handle upward into position and secure with shoulder bolt (C). See figure 3.




FIGURE 3

5. Tighten both shoulder bolts securely.

## OPERATION

1. Service engine with gas and oil. See engine manual packed with log splitter for complete instructions for the care and maintenance of engine. READ DIRECTIONS CAREFULLY.



You must not operate log splitter without proper amount of oil in reservoir tank.

2. Remove the breather cap from reservoir tank. See figure 4.




FIGURE 4

1. The hydraulic system take 4-1/2 gallons of 10W 30 HD only detergent oil. Fill the reservoir tank to the bottom of the fill tube.



**NOTE**

You can not get all the oil in the system until after the engine is run. Replace the breather cap.

## BEFORE STARTING

During initial break-in period, oil level should be watched closely. See ENGINE MAINTENANCE.

Use MS classification oil. Do not use oils marked only MM or ML or unmarked.

Above 32° use SAE 30; below 32° use SAE 10W. These recommendations must be followed for best performance and long life.

Change oil first two (2) hours of operation and check oil level every five (5) operating hours or each time equipment is used.

Change oil every twenty-five (25) operating hours or sooner if equipment is operated in extremely dusty or dirty conditions.



**NOTE**

Carburetors are preset at the factory. DO NOT attempt to make adjustments at this time. See carburetor instructions outlined under CARBURETOR ADJUSTMENT.




FIGURE 5

## TO START ENGINE

1. Place control lever (on engine) in run position. See figure 6.
2. Move choke lever to CHOKE position. See figure 7.
3. Rewind starter—use quick full arm stroke. Keep firm grip on handle and return rope slowly.

## TO STOP ENGINE

1. Move control lever to STOP position. See figure 6.
2. Remove high tension wire from spark plug to prevent accidental starting by children while equipment is unattended.




FIGURE 6

## USING YOUR LOG SPLITTER

Your log splitter is designed for safe, efficient, operation. CARE, OF COURSE, MUST BE EXERCISED THAT HANDS ARE KEPT AWAY FROM MOVING PARTS.

- A. Set throttle at maximum speed.
- B. Engagement handle has three positions: Forward—moves ram toward wedge. Neutral—ram stops in place. Reverse—ram returns. See figure 8.




FIGURE 8

- C. Maximum length that can be split is 23".
- D. Place log on beam and hold in place with right hand. See figure 9.




FIGURE 9




FIGURE 7



After engine has been serviced, finish filling oil reservoir. Start engine and operate engagement handle so the ram makes two complete strokes.



This is to purge the hydraulic system of air. Continued operation will cause permanent damage to pump and cylinder. Stop engine and finish filling reservoir tank. It will take about 3 quarts of oil. See figure 4.

- E. Slowly move engagement handle forward until ram rests against log. Release engagement handle (Neutral).
- F. Remove your hand from the log and step behind the ram. See figure 10.




FIGURE 10

- G. Move engagement handle forward until log is split.



#### NOTE

If you attempt to run the ram beyond its normal stroke it will automatically return the engagement handle to neutral.

- H. Move the engagement handle to the rear to return ram.



#### DANGER

Never attempt to cut a log in half with the log splitter. See figure 11.

Never stand next to the ram when operating. See figure 12. Always stand behind the ram.




FIGURE 11



FIGURE 12

## MAINTENANCE



#### CAUTION

If the ram takes more than 30 seconds to complete a full cycle, the cam plate needs to be adjusted. (See page 10)



#### WARNING

Always stop engine and disconnect spark plug wire before doing any maintenance.

#### RAM OPERATION

If the ram does not move smoothly, run the ram its full stroke several times to clear out air in the system. If this does not correct the problem see strainer tube assembly paragraph. (Page 8).

## RETURN COLLAR

Adjust the return collar so it is 2 inches from the front edge of the wedge. See figure 13.




FIGURE 13

## HOSE CLAMPS

Check the hose clamps on the bottom of the pump for proper tightness before each use. See figure 14.

Hose clamps on the return hose should be checked once a season. See figure 15.




FIGURE 14




FIGURE 15

## OIL RESERVOIR

It is important to keep the oil clean in the reservoir tank. Replace with  $4\frac{1}{2}$  gallons of 10W 30 HD only detergent oil if contaminated (e.g. water in tank).

## BREATHER CAP

Clean breather cap when dirty. See figure 4.

- A. Wash breather in detergent and water.
- B. Air dry.
- C. Lubricate with one tablespoon of 10W 30 oil.

## STRAINER TUBE ASSEMBLY

If the ram does not move back and forth smoothly the strainer tube assembly may be clogged.

To clean follow these steps.

- A. Remove your engine bolts and lockwashers. See figure 16.




FIGURE 16

- B. Loosen hose clamps (either one) on the bottom of the pump.
- C. Lift engine and pump assembly and rotate to one side. See figure 16.
- D. With a wrench, remove strainer tube assembly. See figure 16.

- E. Clean and reassemble using a hydraulic sealant on the threads.

## ENGINE MAINTENANCE

To obtain long life and trouble-free service from your engine, certain normal maintenance must be performed as outlined below:

1. Change oil in crankcase after first two (2) hours of operation. Then, follow instructions outlined on page 5.




FIGURE 17



### CAUTION

Disconnect high tension wire at spark plug to prevent accidental starting of engine. Unscrew oil drain plug located on side at bottom of engine. See figure 17.



### NOTE

Always tip engine towards oil drain hole. Be sure oil drains completely.

Replace oil drain plug and refill with oil as directed on page 5 or engine nameplate.

2. Check oil every five (5) operating hours or each time equipment is used.

3. Cleaning engine—This is an aircooled engine which operates most efficiently when the cooling fins are clean.

Clean cylinder fins and underside of tank or housing thoroughly of all accumulated grass and debris.

4. Air Cleaner. (See figure 18.)

- a. Paper Type Element. Remove every 10 hours or oftener if under dusty conditions. Tap to remove loose dirt and/or blow from inside out with low pressure air. Replace if torn or perforated or when plugged to maintain proper carburetor setting (50 hours). DO NOT WASH IN ANY LIQUID AND DO NOT OIL.




FIGURE 18

### CARBURETOR ADJUSTMENTS (See figure 19)

Do not make unnecessary adjustment. Factory settings are correct for most application. If adjustments are needed, proceed as follows:

1. Close power adjusting needle (figure 19) by turning to right (clockwise). Close finger tight only. Forcing will cause damage.
2. Open one turn (counterclockwise).
3. Close idle adjusting needle (figure 19) by turning to right (clockwise). Close finger tight only. Forcing will cause damage.
4. Open one and one-half (1-1/2) turns (counterclockwise).
5. Start engine. Follow starting instructions page 5.
6. With throttle open (carburetor control at RUN or FAST position) adjust power adjusting needle one-eighth (1/8) turn at a time forward to backward until engine runs smoothly. If engine tends to stall under load enrich mixture slightly (counterclockwise).

7. Hold throttle lever closed or move carburetor control to IDLE or SLOW position and adjust idle adjusting needle until engine runs smoothly proceeding in step six (6) above.
8. Allow several seconds between each adjustment when performing either step six (6) or seven (7) to allow engine to react to new setting.




FIGURE 19

## VALVE ADJUSTMENT

The Cam Plate needs adjusting when:

1. The ram does not make a complete cycle in less than 30 seconds.\*
2. The ram returns slowly.\*
3. The Power Stroke is too slow.\*

\* Engine must be running at full speed.

To adjust, loosen the two nuts and bolts holding the Cam Plate to the Valve, raise it up and tighten the nuts and bolts. Test the operation of the Log Splitter. It should cycle in less than 30 seconds. (See figure 20)




FIGURE 20

To verify the proper adjustment, check the travel distance of the spool from the cast iron housing. (See figures 21 and 22)




FIGURE 21




FIGURE 22

#### Pressure Relief Valve Setting.

If the pressure relief valve is set too low it will open up before enough pressure is built up to properly operate the ram. (See figure 23)

#### To set the Pressure Relief Valve:

1. Remove the acorn nut on the Relief Valve.
2. Loosen the locknut.
3. Have someone place a log crossways in the Splitter and allow the Ram to push against it with the engine running wide open.
4. If the engine begins to lug down, the Relief Valve setting is correct.
5. If adjustment is necessary, tighten the screw until the engine begins to lug down.

Shut off the engine, tighten the locknut and replace the acorn nut.




FIGURE 23

## STORAGE INSTRUCTIONS

In event engine is to be stored for any length of time (30 days or more), prepare as follows:

1. Drain gasoline by tipping or by syphon hose, then run engine until remainder is used and tank and carburetor are empty.




**CAUTION**

Drain into container outdoors away from fire or flame.

2. Drain carburetor by running engine until it stops
3. Inside protecting of engine for storage is performed by removing spark plug and pouring one ounce of SAE 30 oil through spark plug hole into cylinder. Crank engine, without starting, several times to spread oil over cylinder walls.
4. Never store outside without a waterproof cover.

# 248-640A

753-204 SERVICE KIT



# PARTS LIST FOR LOG SPLITTER MODEL 248-640A

Ref. No.	Part No.	Color Code	Description	New Part	Ref. No.	Part No.	Color Code	Description	New Part
1	737-0154		Cylinder Nipple .75" Dia. x 4.50 Lg.		28	738-0258		Shoulder Scr. 3/8-16 Thd.	
2	732-0342		Spring Clamp		29	749-0251		Engagement - Handle	
3	710-0376		Hex Scr. 5/16-18 x 1.00" Lg.*		30	08118		Grip	
4	736-0119		L.-Wash. 5/16" Scr.*		31	737-0152		High Pressure Elbow	
5	13304		Cylinder Ass'y.		32	717-0363		Pump-Complete	
6	13310		Cylinder Holding Plate		33	710-0528		Hex Scr. 5/16-18 x 1.25" Lg.*	
7	736-0119		L.-Wash. 5/16" Scr.*		34	726-0173		Hose Clamp	
8	710-0528		Hex Scr. 5/16-18x1.25" Lg.*		35	727-0205		Inlet Hose	
9	732-0341		Cylinder Return Spring		36	727-0204		Return Hose	
10	721-0159		"O"-Ring		37	710-0494		Sq. Hd. Set. Scr. 5/16-18 x .38" Lg.	
11	721-0164		Teflon Backup Ring	N	38	711-0169		Collar	
12	13302		Push Cylinder Ass'y.		39	734-0584		Wheel Ass'y. Comp.	
13	13314		Spring Hook Ass'y.		40	736-0237		Fl.-Wash. .656 I.D.x1.00" O.D.	
14	13305		"I" Beam - Ass'y. Comp.		41	13276		Tank Ass'y. Comp.	
15	13312		Return Collar Ass'y.		42	13280		Strainer Tube Ass'y.	
16	710-0494		Sq. Hd. Set. Scr. 5/16-18 x .38" Lg.		43	751-0224		Breather Cap	
17	13291		Engagement Lever Ass'y.		44	736-0119		L.-Wash. 5/16" Scr.*	
18	737-0153		Return Elbow		45	712-0267		Hex Nut 5/16-18 Thd.*	
19	717-0364		Valve		46	13295		Coupling Support Brkt. Ass'y.	
20	711-0660		Clevis Pin		47	736-0119		L.-Wash. 5/16" Scr.*	
21	736-0142		Fl.-Wash. .281 I.D. x .50 O.D.		48	710-0528		Hex Scr. 5/16-18x1.25" Lg.*	
22	714-0507		Cotter Pin 3/32" Dia. x .75" Lg.*		49	-----		Engine	
23	714-0114		Sq. Key 1/4" x 2.00" Lg.*		50	712-0241		Hex Nut 3/8-24 Thd.*	
24	736-0119		L.-Wash. 5/16" Scr.*		51	736-0169		L.-Wash. 3/8" Scr.*	
25	717-0374		Flexible Coupling Comp.		52	737-0155		Reducing Bushing	
26	710-0237		Hex Scr. 5/16-24x.62" Lg.*		53	710-0331		Hex Scr. 3/8-24 x 2.25" Lg.*	
27	727-0203		High Pressure Hose Ass'y.		54	13275		Cam Plate	
					55	737-0151		Inlet Nipple	

\*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

The engine is not under warranty by the log splitter manufacturer. If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines - Gasoline."



Maintenance - oil change after first 2 hours  
check every 5 hours

DO NOT CHANGE IDLER SETTINGS

4 1/2 Gallons ~~10W-30~~ <sup>30</sup> HD ONLY DETERGENT

# PARTS INFORMATION

## POWER EQUIPMENT PARTS AND SERVICE

Parts and service for all MTD manufactured power equipment are available through the authorized service firms listed below. All orders should specify the model number of your unit, parts number, description of parts and the quantity of each part required.

<b>ALABAMA</b>	<b>BIRMINGHAM</b>
Auto Electric & Carburetor Co. ....	2625 4th Ave. S. .... 35233
<b>ARKANSAS</b>	<b>NORTH LITTLE ROCK</b>
Sutton's Lawn Mower Shop .....	Rt. 4, Box 368 .... 72117
	<b>FORT SMITH</b>
Mity Mite Motors, Inc. ....	2515 Tawson Ave. .... 72901
<b>CALIFORNIA</b>	<b>PORTERVILLE</b>
Billious .....	75 North D Street .... 93257
	<b>SAN BERNARDINO</b>
Lawn Mower Supply Co. ....	25608 E. Baseline .... 92410
	<b>SAN FRANCISCO</b>
J.W. Jewett Co. ....	981 Folsom St. .... 94107
	<b>SACRAMENTO</b>
Luttig & Severson .....	2030 28th St. .... 95818
<b>COLORADO</b>	<b>DENVER</b>
South Denver Lawn Equip. ....	527 West Evans .... 80223
<b>CONNECTICUT</b>	<b>SUFFIELD</b>
The Janes & Ramsey Co. ....	850 Thampsanville Rd. .... 06078
<b>FLORIDA</b>	<b>JACKSONVILLE</b>
Radco Distributars .....	2403 Market St. .... 32206
	<b>CORAL GABLES</b>
Moz-All of Florida, Inc. ....	365 Greco Ave. .... 33146
<b>GEORGIA</b>	<b>EAST POINT</b>
East Point Cycle & Key .....	2834 Church St. .... 30344
<b>ILLINOIS</b>	<b>LYONS</b>
Keen Edge Co. ....	861S Ogden Ave. .... 60534
<b>INDIANA</b>	<b>ELKHART</b>
Parts & Sales Inc. ....	2101 Industrial Pkwy. .... 46514
<b>IOWA</b>	<b>DUBUQUE</b>
Power Lawn & Garden Equip. ....	2551 J.F. Kennedy .... S2001
<b>LOUISIANA</b>	<b>NEW ORLEANS</b>
Suhren Engine Co. ....	8330 Earhart Blvd. .... 70118
<b>MARYLAND</b>	<b>TAKOMA PARK</b>
Center Supply Co. ....	6867 New Hampshire Ave. 20012
<b>MASSACHUSETTS</b>	<b>SPRINGFIELD</b>
Morton B. Callins Co. ....	300 Birnie Ave. .... 01107
<b>MICHIGAN</b>	<b>MOUNT CLEMENS</b>
Power Equipment Dist. ....	36463 South Gratiot .... 48043
	<b>LANSING</b>
Lorenz Service Co. ....	2500 S. Pennsylvania .... 48900
<b>MINNESOTA</b>	<b>MINNETONKA</b>
Hance Distributing Inc. ....	11212 Wayzata Blvd. .... S5343
<b>MISSISSIPPI</b>	<b>BILOXI</b>
Biloxi Sales & Service, Inc. ....	506 Caillavet St. .... 39533
<b>MISSOURI</b>	<b>KANSAS CITY</b>
Automotive Equip. Service .....	3117 Holmes St. .... 64109
	<b>ST. LOUIS</b>
Henzler, Inc. ....	2015 Lemay Ferry Rd. .... 63125
<b>NEW JERSEY</b>	<b>BELLMAWR</b>
Lawnmower Parts Inc. ....	717 Creek Rd., P.O. Box 7 08030

## BRIGGS & STRATTON, TECUMSEH AND PEERLESS PARTS AND SERVICE

Briggs & Stratton, Tecumseh and Peerless parts and service should be handled by your nearest authorized engine service firm. Check the yellow pages of your telephone directory under the listing **Engines—Gasoline**, Briggs & Stratton or Tecumseh Lauson.

<b>NEW YORK</b>	<b>CARTHAGE</b>
Gamble Dist., Inc. ....	West End Ave. .... 13619
<b>NORTH CAROLINA</b>	<b>GREENSBORO</b>
Dixie Sales Company .....	327 Battleground Ave. .... 27402
	<b>GOLDSBORO</b>
Smith Hardware Co. ....	515 N. George St. .... 27530
<b>OHIO</b>	<b>WADSWORTH</b>
National Central .....	687 Seville Rd. .... 44281
	<b>CLEVELAND</b>
Bleckrie, Inc. ....	7900 Lorain Ave. .... 44102
	<b>CARROLL</b>
Stebe's Mid-State Mower Supply .	Box 366 .... 43112
	<b>WILLARD</b>
Sunshine Wholesale Tire Outlet .	Route 224 .... 44890
<b>OKLAHOMA</b>	<b>MUSKOGEE</b>
Victory Motors, Inc. ....	605 S. Cherokee .... 74401
	<b>ADA</b>
Ada Auto Supply .....	301 E. 12th St. .... 74820
<b>OREGON</b>	<b>PORTLAND</b>
Kenton Supply Co. ....	8216 N. Denver Ave. .... 97217
<b>PENNSYLVANIA</b>	<b>LANCASTER</b>
Raub Supply Co. ....	James & Mulberry Sts. .... 17604
	<b>PITTSBURGH</b>
Bluemant Co. ....	11125 Frankstown Rd. .... 15235
<b>TENNESSEE</b>	<b>KNOXVILLE</b>
Master Repair Service .....	2423 Broadway, N.E. .... 3791
	<b>MEMPHIS</b>
Memphis Cycle & Supply Co. ....	421 Monroe Ave. .... 381
American Sales & Service, Inc. ...	1922 Lynnbrook .... 38116
<b>TEXAS</b>	<b>DALLAS</b>
Marr Brothers, Inc. ....	423 E. Jefferson .... 75203
	<b>HOUSTON</b>
Bullard Supply Co. ....	2409 Commerce St. .... 77003
	<b>SAN ANTONIO</b>
Catto & Putty, Inc. ....	P.O. Box 2408 .... 78206
	<b>FORT WORTH</b>
Woodsan Sales Corp. ....	1702 N. Sylvania .... 76111
<b>UTAH</b>	<b>SALT LAKE CITY</b>
A-1 Engine & Mower Co. ....	437 E. 9th St. .... 84111
<b>VERMONT</b>	<b>BURLINGTON</b>
Vermont Appliance Co. ....	44 Lakeside Ave. .... 05401
<b>VIRGINIA</b>	<b>RICHMOND</b>
RBI Corp. ....	963 Myers St. .... 23260
<b>WASHINGTON</b>	<b>SEATTLE</b>
Bailey's Rebuild, Inc. ....	1325 E. Madison St. .... 98102
<b>WEST VIRGINIA</b>	<b>CHARLESTON</b>
Young's, Inc. ....	233 Virginia St., E. .... 25301
<b>WISCONSIN</b>	<b>APPLETON</b>
Automotive Supply Co. ....	123 S. Linwood Ave. .... S4911

## WARRANTY PARTS AND SERVICE POLICY

The purpose of warranty is to protect the customer from defects in workmanship and materials, defects which are NOT detected at the time of manufacture. It does not provide for the unlimited and unrestricted replacement of parts. Use and maintenance are the responsibility of the customer. The manufacturer cannot assume responsibility for conditions which it has no control. Simply put, if it's the manufacturer's fault, it's the manufacturer's responsibility; if it's the customer's fault, it's the customer's responsibility.

### CLAIMS AGAINST THE MANUFACTURER'S WARRANTY INCLUDES

1. Replacement of Missing Parts on new equipment.
2. Replacement of Defective Parts within the warranty period.
3. Repair of Defects within the warranty period.

All claims MUST be substantiated with the following information:

1. Model Number of unit involved.
2. Date unit was purchased or first put into service.
3. Date of failure.
4. Nature of failure.